

# TIM'S TECH TIPS

---

When spaying VG-101 with the black cavity wax gun VG-180 it is imperative that the flow adjustment knob at the top rear of the gun is turned in until it is fully closed then opened no more than 1 full turn. Too much product flow combined with excessive air pressure will cause an unsatisfactory output of product and may cause the product to “backflow” out of the air inlet when the air hose is disconnected.

Ideal air input pressure for this application equipment is between 70 -90 psi.

Always disconnect air hose and release air pressure from the gun when finished.

To relief air pressure simply open the gun ¼ turn or until air is heard escaping through bleeder hole.

Tim